4-Dip/ ID-1 / Firmware Z02T17 (Master)
4-Dip/ ID-2 / Firmware Z02T17
4-Dip/ ID-3 / Firmware Z02T17
4-Dip/ ID-4 / Firmware Z02T17
4-Dip/ ID-5 / Firmware Z02T17
4-Dip/ ID-6 / Firmware Z02T17
6-Dip/ ID-7 / Firmware Z02T18
6-Dip/ ID-8 / Firmware Z02T18
6-Dip/ ID-9 / Firmware Z02T18
6-Dip/ ID-10 / Firmware Z02T18
6-Dip/ ID-11 / Firmware Z02T18
6-Dip/ ID-12 / Firmware Z02T18
6-Dip/ ID-13 / Firmware Z02T18
6-Dip/ ID-14 / Firmware Z02T18
6-Dip/ ID-15 / Firmware Z02T18
6-Dip/ ID-16 / Firmware Z02T18
6-Dip/ ID-17 / Firmware Z02T18
6-Dip/ ID-18 / Firmware Z02T18
6-Dip/ ID-19 / Firmware Z02T18
6-Dip/ ID-20 / Firmware Z02T18
6-Dip/ ID-21 / Firmware Z02T18
6-Dip/ ID-22 / Firmware Z02T18
6-Dip/ ID-23 / Firmware Z02T18
6-Dip/ ID-24 / Firmware Z02T18
Data Communication Flow:
First Battery In Line (Master):
Last Battery In Line (Last Slave):
6-Dip/ ID-43 / Firmware Z02T18
6-Dip/ ID-44 / Firmware Z02T18
6-Dip/ ID-45 / Firmware Z02T18
6-Dip/ ID-46 / Firmware Z02T18
6-Dip/ ID-47 / Firmware Z02T18
6-Dip/ ID-48 / Firmware Z02T18
6-Dip/ ID-37 / Firmware Z02T18
6-Dip/ ID-38 / Firmware Z02T18
6-Dip/ ID-39 / Firmware Z02T18
6-Dip/ ID-40 / Firmware Z02T18
6-Dip/ ID-41 / Firmware Z02T18
6-Dip/ ID-42 / Firmware Z02T18
6-Dip/ ID-31 / Firmware Z02T18
6-Dip/ ID-32 / Firmware Z02T18
6-Dip/ ID-33 / Firmware Z02T18
6-Dip/ ID-34 / Firmware Z02T18
6-Dip/ ID-35 / Firmware Z02T18
6-Dip/ ID-36 / Firmware Z02T18
6-Dip/ ID-25 / Firmware Z02T18
6-Dip/ ID-26 / Firmware Z02T18
6-Dip/ ID-27 / Firmware Z02T18
6-Dip/ ID-28 / Firmware Z02T18
6-Dip/ ID-29 / Firmware Z02T18
6-Dip/ ID-30 / Firmware Z02T18