Select station first | Glenn Squires | 4462670520 | Read

Common Setting

Time (?) 2026-04-21 12:58: Set

PV Input Mode (?) 4: PV1&2 in Set

Start PV Volt(V) 150 Set

Model

Measurement (?) 1: CT

CT Sample Ratio (?) 1/3000 Set

CT Direction Reversed (?) Enable | Disable

CT Power Offset(W) 0 Set

Battery Type (?) 2: Lithium

Lithium Brand (?) 1 Set Model

Firmware version FAAB-2525

LCD Version 15/1/1

Application Setting

No Batteries (?) Enable | Disable

Power Backup (?) Enable | Disable

Seamless EPS switching (?) Enable | Disable

Grid Sell Back (?) Enable | Disable

Grid Sell Back Power(kW) (?) 8 Set

Fast Zero Export (?) Enable | Disable

Off-Grid Mode (?) Enable | Disable

PV Arc (?) Enable | Disable

PV Arc Fault Clear (?) Clear

Grid Loss Warning Clear (?) Enable | Disable

RSD (?) Enable | Disable

Normal / Standby (?) Normal | Standby

Restart Inverter (?) Restart

Micro-Grid (?) Enable | Disable

Max. AC Input Power(kW) (?) 5 Set

System Charge SOC Limit(%) 95 Set

System Charge Volt Limit(V) 59.5 Set

Parallel System

Set System Type (?) 1 Phase Master Set Share Battery (?) Enable Disable

Set Composed Phase (?) Phase Phase Set Parallel Setting Data Sync (?) Enable Disable

System Grid Connect Setting

Grid Type (?) 0: 240V/120V Set

Charge Setting

Batt Charge Control (?) Volt SOC Charge Current Limit(Adc) (?) 200 Set

Charge Last (?) Enable Disable

Battery Backup Mode Enable Disable

AC Charge

AC Charge Enable (?) Enable Disable AC Charge Based On (?) Time Set AC Charge Power(kW) (?) 1 Set

Start AC Charge SOC(%) 70 Set Start AC Charge Volt(V) 44 Set

Stop AC Charge SOC(%) 95 Set Stop AC Charge Volt(V) 56 Set

AC Charge Start Time 1 20 : 30 Set AC Charge Start Time 2 00 : 00 Set AC Charge Start Time 3 00 : 00 Set

AC Charge End Time 1 05 : 30 Set AC Charge End Time 2 00 : 00 Set AC Charge End Time 3 00 : 00 Set

Battery Backup Mode

PV Charge Priority (?) Enable Disable PV Charge Power(kW) 12 Set

PV Charge Priority Stop SOC(%) (?) 100 Set PV Charge Priority Stop Volt(V) 56 Set

Battery Priority Start Time 1 00 : 00 Set Battery Priority Start Time 2 00 : 00 Set Battery Priority Start Time 3 00 : 00 Set

Battery Priority End Time 1 00 : 00 Set Battery Priority End Time 2 00 : 00 Set Battery Priority End Time 3 00 : 00 Set

Generator Charge

Generator

Generator Boost: Enable / Disable

Generator Cool-Down Time(Min): 0.4 Set

Batt Charge Current Limit(Adc) (?): 60 Set

Gen Rated Power(kW) (?): 12 Set

Charge Start Volt(V) (?): 40 Set

Charge Start SOC(%): 10 Set

Charge End Volt(V): 56 Set

Charge End SOC(%): 100 Set

Discharge Setting

Batt Discharge Control (?): Volt / SOC

Discharge Current Limit(Adc) (?): 250 Set

Start Discharge P_import(W) (?): 0 Set

On-Grid Cut-Off SOC(%) (?): 20 Set

Off-Grid Cut-Off SOC(%) (?): 20 Set

On-Grid Cut-Off Volt(V) (?): 51 Set

Off-Grid Cut-Off Volt(V) (?): 51 Set

Forced Discharge

Forced Discharge Enable (?): Enable / Disable

Forced Discharge Power(kW) (?): 6 Set

Stop Discharge SOC(%) (?): 20 Set

Stop Discharge Volt(V): 4 Set

PVSellToGrid(Comp. w/ NEM3.0) (?): Enable / Disable

Forced Discharge Start Time 1: 00 : 00 Set

Forced Discharge Start Time 2: 00 : 00 Set

Forced Discharge Start Time 3: 00 : 00 Set

Forced Discharge End Time 1: 00 : 00 Set

Forced Discharge End Time 2: 00 : 00 Set

Forced Discharge End Time 3: 00 : 00 Set

Peak Shaving

Grid Peak-Shaving (?): Enable / Disable

Grid Peak-Shaving Power 1(kW) (?): 0 Set

Grid Peak-Shaving Power 2(kW) (?): 0 Set

Start Peak-Shaving Volt 1(V): 52 Set

Start Peak-Shaving Volt 2(V): 52 Set

Start Peak-Shaving SOC 1(%): 21 Set

Start Peak-Shaving SOC 2(%): 21 Set

Peak Shaving Start Time 1: 05 : 30 Set

Peak Shaving Start Time 2: 17 : 30 Set

Peak Shaving End Time 1: 08 : 30 Set

Peak Shaving End Time 2: 20 : 30 Set

AC Couple

AC Couple (?): Enable / Disable

AC Couple Start Volt(V)	59.5	Set	AC Couple Start SOC(%)	100	Set
AC Couple End Volt(V)	80	Set	AC Couple End SOC(%)	255	Set

Smart Load

Smart Load (?)	Enable / Disable				
Start PV Power(kW) (?)	0.5	Set	Grid Always On (?)	Enable / Disable	
Smart Load Start Volt(V)	54	Set	Smart Load Start SOC(%)	90	Set
Smart Load End Volt(V)	48	Set	Smart Load End SOC(%)	60	Set

Battery

Read

- [ ] Restart Battery Module 0
- [ ] Restart Battery Module 1

Restart Battery Module

Reset

All to Default: Reset

Clear Function: Set